

				
PAT	PT125EL	PAC3760DL	PrimeTest Pro Kit	PrimeTest Elite+ Kit
Accurate earth continuity circuit	•	•	•	•
Mains supply check	•	•	•	•
IEC lead test	•	•	•	•
Earth continuity (200mA)	•	•	•	•
Insulation resistance	500V	250V/500V	250V/500V	250V/500V
Touch current		•	•	•
Alternative substitute leakage	•	•	•	•
RCD test		•	•	•
3 phase leakage		Requires adaptor	Requires adaptor	Requires adaptor
Compact, light and handheld	•	•	•	•
Color Screen			•	•
Internal memory		Up to 999 records	Up to 10,000 records	Up to 50,000 records & 2,000 photos
Scanner & printer compatibility		Printer Only	• Scanner & Printer	• Scanner & Printer
Password controlled user account			•	•
Clone facility to set up multiple testers			•	•
On-board camera				•
Download to PC via USB cable			•	•
Data transfer via USB flash drive				•
Filter results to be downloaded			•	•
Upload previous results to tester for retest			•	•
PATGaurd 3 Software			•	•
3 phase leakage adaptor		•	•	•
Ideal for	In-house Testing	In-house Testing with simple record keeping	Asset Management and PAT Testing Services	Asset Management and PAT Testing Services
Cost	ETL Website	ETL Website	ETL Website	ETL Website

Note - PT125EL and PAC3760DL don't allow for the upload of Logos and text inputs such as company names.